



### 3. MAINTENANCE REQUIREMENTS

#### 3.1. "A" Maintenance Requirements (at 5,000 mile intervals)

- Change oil and filter;
- Chassis lubrication;
- Check all fluid levels, which include:
  - Power steering;
  - Master cylinder;
  - Transmission fluid;
  - Windshield washer;
  - Battery; and Radiator coolant.
- Check tire condition and pressure;
  - Rotate and balance (if necessary); and,
  - Check spare.
- Check for proper operation of the following:
  - Windshield wiper and washer;
  - All lights and reflectors;
  - Horn;
  - Heater and air conditioner;
  - Emergency brake;
  - Radio.
- Check for fluid leaks.

#### 3.2. "B" Maintenance Requirements ("A" Maintenance, plus the following at 20,000 mile intervals)

- Check and replace air and fuel filters;
  - Replace P.C.V. valve , if necessary;
  - Clean and protect battery terminal ends;
- Check brakes;
- Check shocks;
- Check front wheel bearing on rear drive vehicles; and,
- Check drive axle boots on front drive vehicles.

#### 3.3. "C" Maintenance Requirements ("A" and "B" Maintenances, plus the following at 60,000 mile intervals)

- Replace all belts and hoses, if necessary (no hoses replacement, if vehicle has extended life coolant);
- Service transmission; and,
- Complete detail clean (w/o engine clean).